



OMEGA Internal Chamber Block

These Instructions intended for automatic pistols of caliber: .22 LR, .25 ACP, .32 ACP, .380 ACP, .9 MM, .40 S&W, .45 ACP, FN57, AE-50

The Omega Internal Chamber gun blocking system is designed to help you keep your firearm stored in a safe condition. This block does not relieve the handler of the firearm from always paying strict attention to gun safety rules. For protection from theft, the use of a safe or other secure system designed to secure your firearms is recommended. Always observe all of these warnings and instructions when using this gun block.

READ THE OWNERS MANUALS SUPPLIED WITH YOUR FIREARM & BLOCK. KEEP FIREARMS AND AMMUNITION STORED SEPARATELY AND SECURELY. KEEP FIREARMS AND AMMUNITION OUT OF REACH OF CHILDREN.

THIS BLOCK IS FOR USE AS AN AID TO YOUR SAFETY MEASURES. GUN BLOCKS ARE NOT A SUBSTITUTE FOR SAFE FIREARM HANDLING AND STORAGE. SAFETY AND SAFE FIREARMS HANDLING IS EVERYONE'S RESPONSIBILITY. Do not dry fire the chamber locks, as damage could occur to the block, voiding the warranty

The use of the Omega chamber block will help prevent your firearm from being used (discharged) by unauthorized persons. This block is not designed to prevent theft. Strict safety practices should always be followed even when your gun is blocked.

www.omegagunlock.com

BEFORE INSTALLING YOUR OMEGA CHAMBER BLOCK

Note: Your Omega chamber block is custom designed to fit only the caliber you purchased it to block.

Only use this chamber block on the designated automatic handgun caliber(s). This block is not designed for use on multiple firearms.

WARNING: Do not over tighten the block. Do not leave the block expanded outside of the firearm. These actions may void the warranty.

Before inserting the block into your firearm, holding the front of the block, engage the key into the block, turning counter clockwise until the key stops turning. This ensures that the expandable ring is totally relaxed (not expanded). Then turn key 1/8th turn (45 degrees) clockwise. This ensures the free movement of the screw inside the block. Your block is now ready to insert into your firearm. With each continued use of the Omega chamber block, the blocking ring conforms to fit tighter in the chamber.

- Unload all ammunition in a safe manner as explained in the firearm's owner's manual.
- Put your gun's safety mechanism in the "on safe" position as explained in the owner's manual supplied with your firearm.
- Visually inspect the chamber, feed mechanism and magazine to assure yourself that the firearm is completely unloaded, and that the chamber is clean, dry and free of obstructions.

OMEGA CHAMBER BLOCK INSTALLATION FOR AUTOMATIC HANDGUNS

- Open and block the slide on your automatic to reveal the chamber. Insert the block into the chamber and close the slide. (See Figures 1 & 2)
- Insert the self-centering key down the front barrel of your firearm until it meets the head of the chamber block. Turn slightly until you feel key drop into block. (See Figure 4)
- Holding firearm in one-hand, **WHILE PUSHING FORWARD** toward muzzle end, turn key clockwise 90 degrees with your other hand. As you would tighten any nut with a wrench, continue to tighten the block until slight resistance is felt (See Figure 5).

UNLOCKING OMEGA CHAMBER LOCK FOR AUTOMATIC HANDGUNS

- Insert key into the barrel and turn counter-clockwise until there is no tension on key.
- Pull back the slide. Push the block out of the chamber, remove from firearm.
- Your firearm is immediately ready for use.

WARNING: NEVER INSTALL GUN BLOCK ON A LOADED FIREARM.

WARNING: STORE THE GUN BLOCK KEY IN A SEPARATE LOCATION FROM YOUR FIREARM. ALL FIREARMS SHOULD BE STORED AWAY FROM CHILDREN.

WARNING: IF GUN BLOCK OR KEY BECOMES DAMAGED IN ANY WAY DO NOT ATTEMPT TO USE ON FIREARM. REFER TO GUARANTEE SECTION FOR REPLACEMENT INFORMATION.

CAUTION: NEVER STORE BLOCK WITH ITS RINGS EXPANDED (IN THE LOCKED, TIGHTENED POSITION) OUTSIDE THE FIREARM, AS DAMAGE COULD OCCUR, VOIDING THE WARRANTY.

NOTE: MAKE CERTAIN BLOCK IS CLEAN AND FREE OF DIRT OR OIL AFTER EACH USE. THIS MAINTAINS THE LIFE OF THE LOCK.

Limited Warranty

Omega warrants the Block is free from defects in material and workmanship. The Block meets the requirements of California Penal Code § 12088.1, as of January 1, 2002, for a firearms safety device for the type of firearm identified on the packaging of the Block. In addition, if the Block is damaged as a result of unauthorized use, Omega will replace it free of charge. Simply send the damaged Block to Omega along with your name, address and \$4.95 per Block for postage and handling. This warranty is valid for 90 days from date of purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Disclaimer of Warranties

There are no warranties which extend beyond the face of this limited warranty. Omega disclaims all other warranties, express or implied, regarding the Block, including any implied warranties of merchantability or fitness for a particular purpose. No gun block offers complete protection against the accidental or intentional misuse of firearms. Given sufficient time, energy or tools, any blocking device can be compromised.

Limitation of Remedies

Your exclusive remedy if the Block is defective is limited to the repair or re-placement of the defective Block. Send the defective Block to Omega along with your name and address. Omega will send you a new or repaired Block. If Omega does not repair or replace a defective Block, Seller will refund the purchase price of the defective Block.

Limitation of Damages

Omega's entire liability for any defective Block shall in no event exceed the purchase price for the defective Block. This limitation applies even if Omega cannot or does not repair or replace any defective Block and your exclusive remedy fails of its essential purpose.

No Consequential or Other Damages

Omega has no liability for general, consequential, incidental or special damages, including any damages arising out of the owner's or another person's personal injury or loss of life. Some states do not allow exclusion or limitation of incidental or consequential damages, so the limitations above may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Obtaining Service

If you have a claim under this warranty please contact us at: Omega Safety Systems, Inc., P.O. Box 1517, Idyllwild, CA 92549, Tel: 1-951-659-7778. When you contact us, please provide us with your name, address, telephone number, and a brief description of the problem with the Block that you are using.

Firearm Safety Device Safety Tips

- All firearms should always be assumed to be loaded and should be handled as such.**
- Learn the mechanical and handling characteristics of the firearm you are using.**
- Don't rely on your gun's "safety."**
- Keep firearms pointed in a safe direction at all times, even when unloaded.**
- Store firearms unloaded, blocked, and in an out-of-sight location out of the reach of children.**
- Store ammunition separately under lock and key.**
- Store gun block key in a place separate from the gun.**
- Gun blocks are not a substitute for safe firearm handling and storage.**
- Safety and safe firearms handling is everyone's responsibility.**
- Teach children basic principles of firearm safety. When encountering a gun: DO NOT TOUCH IT! TELL AN ADULT!**

Laws concerning firearms ownership, storage and handling vary among states and local jurisdictions. Learn and comply with your state and local laws and those of any jurisdiction to which you plan to transport or use firearms.

For further orders or to contact Omega:

www.omegagunlock.com




Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5




Fig. 6